

**INSTALLATION INSTRUCTIONS**

- 1.) INSTALL COLUMN ONTO PRE-INSTALLED FOOTER BY OTHERS OR ATTACH WITH CONCRETE ANCHORS AS REQUIRED. ENSURE ALL SIDES ARE PLUMB WITH A LEVEL.
- 2.) INSTALL THE ARM ASSEMBLY ONTO THE THE TOP OF THE COLUMN, USING 3/8"-16 x 3 1/2" BOLTS, (TWO (2) WASHERS, ONE (1) LOCK WASHER AND ONE (1) NUT PER BOLT)



Ball Ground, Ga. 30107  
www.awnexinc.com  
Ph. 770-704-7140 Fax 770-704-7647

<b>ATLANTA CLEARANCE BAR</b>			
<b>INSTALLATION INSTRUCTIONS</b>			
<small>PROJECT NAME:</small>		<small>BY</small>	
<small>DRAWING NAME:</small>		JAJ	
<small>CUSTOMER:</small>		<small>DATE</small>	<small>DESCRIPTION</small>
<small>REV</small>			PRODUCTION DRAWINGS

**SHIPPING ADDRESS:**

**CONTRACTOR:**

CONTACT: N/A  
PHONE#: N/A  
CELL#: N/A

<small>DWN BY:</small> JAJ	<small>CHK BY:</small> ZMB	<small>ENG. BY:</small>
-------------------------------	-------------------------------	-------------------------

SCALE: 1'-0"=1'-0"  
SHT. NO: **I-1.00**

Reproduction of this document without the written authorization of AWNEX Inc. is strictly prohibited. Copyright 2020 AWNEX Inc.