

INSTALLATION INSTRUCTIONS

- 1.) INSTALL COLUMN ONTO PRE-INSTALLED FOOTER OR ATTACH WITH CONCRETE ANCHORS AS REQUIRED. PIVOT STOP SHOULD BE AT THE BACK LEFT FROM TRAFFIC. ENSURE ALL SIDES ARE PLUMB WITH A LEVEL.
- 2.) INSTALL THE ARM ASSEMBLY ONTO THE PIVOT ASSEMBLY AT THE TOP OF THE COLUMN, USING 3/8"-16 x 3 1/2" BOLTS, (TWO (2) WASHERS, ONE (1) LOCK WASHER AND ONE (1) NUT PER BOLT)



Ball Ground, Ga. 30107
 www.awnexinc.com
 Ph. 770-704-7140 Fax 770-704-7647

PROJECT NAME: CLEARANCE BAR - PIVOTED			
DRAWING NAME: INSTALLATION INSTRUCTIONS			
CUSTOMER:			
REV	DATE	BY	DESCRIPTION
-		MTH	PRODUCTION DRAWINGS

SHIPPING ADDRESS:

CONTRACTOR:

CONTACT: N/A
 PHONE#: N/A
 CELL#: N/A

DWN BY:	CHK BY:	ENG. BY:
MTH	ZB	

SCALE: 1'-0"=1'-0"
 SHT. NO: **I-1.00**

Reproduction of this document without the written authorization of AWNEX Inc. is strictly prohibited. Copyright 2020 AWNEX Inc.